

Club Member User Codes for W4BKD Repeater

You **must ID** before you use these functions.
DO NOT ID after, but before.

To make a LOCAL telephone call	Press 119 then the number (all at one time)
To disconnect the call	Press 10
To play your input audio back	Press 69 unkey (Repeater responds READY) Talk into your mic and unkey
To read signal strength back	Press 70
To play current time and Temp	Press 71
DTMF Read back	Press 85 followed by any keypad numbers (Then unkey)
To transmit repeater location	Press 20
To hear date and time	Press 36